


SDR pneumatic and direct seeder with tines



Standard equipment:

- › **1** Independent sowing arms in four rows with spacing between rows 470 mm, tines 20 mm with tungsten carbide inserts. Clearance under chassis 610 mm..
- › **2** Simple raking in three sections (in one section for SDR 300).
- › **3** 3 functions basic controller:
 - › Account-hectares.
 - › R.p.m. turbine.
 - › Fill sensor.
- › **4** Mechanical turbine with cardan transmission TFT 1000 r.p.m..
- › **5** Hydraulic jacks for augers.
- › **6** Wheels 340/55-16" and Control wheels depth in wings from 5.00 m.
- › **7** Rear lights kit and work lights kit.
- › **8** Hopper selector screen.



4 rows sowing train

CODE	MODEL	ARMS	ARMS SEP. (cm)	CAPACITY (L)	WIDTH (m)		WEIGHT (kg)	POWER (CV)
					Work	Total		
1021060041	SDR 300-4-19	19	16	2000	3	3	1.625	120-140
1021060042	SDR 400-4-25	25	16	2000	4	3	2.100	140-180
1021060043	SDR 500-4-31	31	16	2000	5	3	2.520	180-210
1021060044	SDR 600-4-37	37	16	2000	6	3	2.950	210-240

Options

Rollers



ROLLER CAGE Ø 25 cm. 8 bars 20 mm

CODE	MODEL	WORK WIDTH (m)	WEIGHT (Kg)
2021060020	SDR-300	3	180
2021060021	SDR-400	4	240
2021060022	SDR-500	5	300
2021060023	SDR-600	6	350

Other options



Kit of compactor wheel for SDR arm (Price per arm)

CODE
2021060006



Loading auger

CODE
2021050054



Hydraulic transmission difference (tractor oil)

CODE
2021050025



Hydraulic tracer set (Discos dentados)

CODE
2021060015



Close independent outputs folding parts

CODE	MODEL
2021060002	SDR 400
2021060003	SDR 500
2021060004	SDR 600

Total sowing cut

CODE
2021050024

Tramlines sowing 2x2

CODE
2021050059



Increment for electronic controller with 5 functions:

- › Account hectares.
- › RPM turbine.
- › Control of forward speed.
- › Fill sensor.
- › Turn dispenser filling alarm.

CODE
2021050029



Wheel brake

CODE
2021050027



LED work lights

CODE
2029000001



Planting electric control

CODE
2021050060



Increase in price for command radar in electric sowing

CODE
2021050064