

SNE-R pneumatic seeder with tines



Standard equipment:

- › **1** Sowing train with hydraulic folding in three-section bodies. (Except SNE-300 with body in one section and SNE-350. Sections with manual folding).
- › **2** 3 functions basic controller:
 - › Account-hectares
 - › R.p.m. turbine
 - › Fill sensor.
- › **3** Raking of springs in three sections. (In one section for the models of 3.00 m)..
- › **4** Independent sowing arms in three and four rows with straight grate in SNE-R.
- › **7** Mechanical turbine with cardan transmission, TFT 1000 r.p.m.
- › **8** Hydraulic jacks for augers.
- › **9** Hopper selector screen.
- › **10** Depth control.
- › **11** Scale control of planting depth.
- › **12** Wheel 10.0/75-15.3" and heavy crank.
- › **13** Depth control wheels on the wings from 5,00 m.
- › **14** Clears traces of seeder
- › **15** Rear lights kit.
- › **16** Level of leveling bubble.



3 rows sowing train with tines arms

CODE	MODEL	ARMS	ARMS SEP. (cm)	CAPACITY (L)	WIDTH (m)		WEIGHT (kg)	POWER (CV)
					Work	Transport		
1021050007	SNE 300-3-24 R	24	12,5	1600	3	3	1080	80-90
1021050010	SNE 350-3-28 R	28	12,5	1600	3,5	3	1175	90-100
1021050013	SNE 400-3-32 R	32	12,5	1600	4	2,5	1200	100-110
1021050017	SNE 450-3-36 R	36	12,5	1600	4,5	2,5	1280	110-120
1021050021	SNE 500-3-40 R	40	12,5	1600	5	2,5	1350	120-130



4 rows sowing train with tines arms

CODE	MODEL	ARMS	ARMS SEP. (cm)	CAPACITY (L)	WIDTH (m)		WEIGHT (kg)	POWER (CV)
					Work	Transport		
1021050014	SNE 400-4-32 R	32	12,5	1600	4	2,5	1250	100-110
1021050018	SNE 450-4-36 R	36	12,5	1600	4,5	2,5	1330	110-120
1021050022	SNE 500-4-40 R	40	12,5	1600	5	2,5	1400	120-130
1021050026	SNE 600-4-40 R	40	15	1600	6	3	1580	130-140
1021050027	SNE 600-4-48 R	48	12,5	1600	6	3	1610	130-140

Standard equipment for SNE-R, SNE-D and SNE-B:



Options for SNE-R, SNE-D and SNE-B

Leveling bar



FOR MODEL:	Level flat bar			Push level bar		
	CODE	WORK WIDTH (m)	WEIGHT (Kg)	CODE	WORK WIDTH (m)	WEIGHT (Kg)
BN 300 SNE	2021050011	3	240	2021050001	3	150
BN 400 SNE	2021050012	4	320	2021050003	4	196
BN 450 SNE	2021050013	4,5	355	2021050004	4,5	203
BN 500 SNE	2021050014	5	390	2021050005	5	212
BN 600 SNE	2021050015	6	425	2021050002	6	270

Sowing preparer

CODE	MODEL	ARMS	ARMS SEP. (cm)	WORK WIDTH (m)	WEIGHT (Kg)
2021050046	SNE 300	10	27,3 cm	300	370
2021050047	SNE 400	14	26,6 cm	400	460
2021050048	SNE 450	16	26,4 cm	450	490
2021050049	SNE 500	18	26,3 cm	500	540



More options for SNE-R, SNE-D and SNE-B



**Hopper increase 2.000 L
SNE (all models)**

CODE

2021050034



Hydraulic tracer set

CODE

2021050039



**Increase disc compactor
wheel tracer set (only for
SNE-D). (Price per disc):**

CODE

2029000002



Loading auger

CODE

2021050054



**Distributor cap 40/20
outputs (for SNE 500)**

CODE

2021050058



**Hydraulic transmission
difference (tractor oil)**

CODE

2021050025



**Increment per wheel
340/55-16"**

CODE

2021050030



**Side wheels for models
of 4,00 m and 4,50 m.**

CODE

2021050037



Wheel brake

CODE

2021050027



**Set mud remover
on side wheels**

CODE

2021050038



LED work lights

CODE

2029000001



**Increase in price for
command radar in
electric sowing**

CODE

2021050064



**Increase for 5 functions
controller**

CODE

2021050029

- › Account-hectares.
- › R.p.m. turbine.
- › Advance speed control.
- › Fill sensor.
- › Turn dispenser filling alarm.

Tramline sowing 2x2 in controller

CODE

2021050059

Total sowing cut

CODE

2021050024



**Close independent outputs folding parts
(only with 5-function electric controller *)**

* Installed in Solano Horizonte

CODE	MODEL
2021050007	SNE 400
2021050008	SNE 450
2021050009	SNE 500
2021050010	SNE 600



Planting electric control

CODE

2021050060