

# SNP-R pneumatic seeder with tines



## 3 rows sowing train with tines arms

CODE	MODEL	ARMS	ARMS SEP. (cm)	CAPACITY (L)	WIDTH (m)		WEIGHT (kg)	POWER (CV)
					Work	Total		
1021050029	SNP 400-3-32 R	32	12,5	1800	4	3	1.770	120-140
1021050031	SNP 500-3-40 R	40	12,5	1800	5	3	2.050	140-160
1021050033	SNP 600-3-40 R	40	15	1800	6	3	2.330	160-180
1021050034	SNP 600-3-48 R	48	12,5	1800	6	3	2.370	160-180



## 4 rows sowing train with tines arms

CODE	MODEL	ARMS	ARMS SEP. (cm)	CAPACITY (L)	WIDTH (m)		WEIGHT (kg)	POWER (CV)
					Work	Total		
1021050030	SNP 400-4-32 R	32	12,5	1800	4	3	1.784	120-140
1021050032	SNP 500-4-40 R	40	12,5	1800	5	3	2.080	140-160
1021050035	SNP 600-4-40 R	40	15	1800	6	3	2.366	160-180
1021050036	SNP 600-4-48 R	48	12,5	1800	6	3	2.406	160-180

### Standard equipment:

- › Raking of springs in three sections.
- › Rear lights kit and work lights kit.
- › Independent sowing arms in three or four rows with straight grate.
- › Depth control to central and lateral wheels.
- › Clears traces of seeder
- › Hopper selector screen.
- › High flotation wheels (340 / 55-16) in 5 and 6 m models.
- › Mechanical turbine with cardan transmission TFT 1000 r.p.m.



### Electronic controller with 5 functions:

- › Account-hectares
- › R.p.m. turbine
- › Advance speed control
- › Fill sensor.
- › Turn dispenser filling alarm

## Options

### Leveling bar

CODE	MODEL	WORK WIDTH (m)	WEIGHT (Kg)
2021050016	BN 400 SNP	4	320
2021050017	BN 500 SNP	5	390
2021050018	BN 600 SNP	6	425



### Sowing preparer

CODE	MODEL	ARMS	ARMS SEP.	WORK WIDTH (m)	WEIGHT (Kg)
2021050042	PS 400 SNP	15	22	4	225
2021050043	PS 500 SNP	19	22	5	252
2021050045	PS 600 SNP	23	22	6	275



Hopper supplement up to 2.000 L.

CODE  
2021050057



Loading auger

CODE  
2021050054



SNP-4 wing floating system and depth control wheels

CODE  
2021050056



Hydraulic transmission difference (tractor oil)

CODE  
2021050025



Difference for homocynetic transmission

CODE  
2021050026



Wheel brake

CODE  
2021050027



Set mud remover on side wheels

CODE  
2021050038



Hydraulic tracer set

CODE  
2021050040



Close independent outputs folding parts\*

CODE	MODEL
2021050007	SNP 400
2021050009	SNE 500
2021050010	SNE 600

Total sowing cut

CODE  
2021050024

Tramlines sowing 2x2

CODE  
2021050059

\* Installed in Solano Horizonte



Set of clear traces eraser and support

CODE  
2021050036